

Audac CMP30, storage of radio stations:

1) Automatic radio station storage

When pressing the "MEMO" button, the CMP30 starts searching automatically for the radio stations.

It starts with at the lower frequencies of the FM band, and starts with Band 1, and Freq 1.

Every time the CMP30 finds a radio station with a signal which is strong enough, it stores the

frequency and searches for the next frequency

2) Manual radio station storage

Select the frequency by using the << and >> buttons.

Once the desired frequency is selected, press:

- Press and Hold the "PLAY/PAUSE" button for storing to "Memo 1"
- Press and Hold the "STOP" button for storing to "Memo 2"
- Press and Hold the "REP" button for storing to "Memo 3"
- Press and Hold the "RAND" button for storing to "Memo 4"
- Press and Hold the "DIR-" button for storing to "Memo 5"
- Press and Hold the "DIR+" button for storing to "Memo 6"

3) Select stored frequency

- Press the "DIR-" and "DIR+" key to switch between the stored frequencies

The CMP30 can store 6 frequencies to each band, and had 5 bands (FM1, FM2, FM3, MW1, MW2)

So total of 30 frequencies can be stored to CMP30 memory.